
















SWITCH & CONTROL FUNCTION


3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
T1	T2	NO TONE	
			← NECK PICKUP
			← MIDDLE PICKUP
			← BRIDGE PICKUP
PICKUP IS OFF → 			← PICKUP IS ON

VOLUME CONTROL  
ALL SWITCH POSITIONS

 3 WAY SWITCH

TONE CONTROL (T1)

TONE CONTROL (T2)



NECK PICKUP

MIDDLE PICKUP

BRIDGE PICKUP