

VOODOO STRATOCASTER 0106602

SWITCH & FUNCTION CONTROL

5 WAY SWITCH POSITION					
					← 5 WAY SWITCH POSITION
T1	T1&T2	T2	T2	—	← TONE CONTROL
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
	PICKUP IS ON				PICKUP IS OFF

