















# YNGWIE MALMSTEEN STRATOCASTER 0107100/7102

## SWITCH & CONTROL FUNCTION

3 WAY SWITCH POSITION			
3 	2 	1 	← 3 WAY SWITCH POSITION
T1	T2	T2	← TONE CONTROL
			← NECK PICKUP
			← MIDDLE PICKUP
			← BRIDGE PICKUP
PICKUP IS OFF → 			← PICKUP IS ON

