

ROADHOUSE STRATOCASTER 0107300/7302

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
5 ● ○ ○ ○ ○	4 ● ○ ○ ○	3 ● ○ ○	2 ● ○ ○	1 ● ○ ○	← 5 WAY SWITCH POSITION
T1	T1&T2	T2	T2	—	← TONE CONTROL
█	█	▭	▭	▭	← NECK PICKUP
▭	█	█	█	▭	← MIDDLE PICKUP
▭	▭	▭	█	█	← BRIDGE PICKUP
█	← PICKUP IS ON			▭	← PICKUP IS OFF

