

# ERIC CLAPTON STRATOCASTER 0107602

## SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
● 5 ○ ○ ○ ○ ○	● 4 ○ ○ ○ ○ ○	○ ● 3 ○ ○ ○ ○ ○	○ ○ ● 2 ○ ○ ○ ○ ○	○ ○ ○ ● 1 ○ ○ ○ ○ ○	← 5 WAY SWITCH POSITION
●	●	○	○	○	← NECK PICKUP
○	●	●	●	○	← MIDDLE PICKUP
○	○	○	●	●	← BRIDGE PICKUP
●	← PICKUP IS ON			○	← PICKUP IS OFF

