

NASHVILLE B-BENDER TELECASTER 0108342

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					← 5 WAY SWITCH POSITION
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
	← PICKUP IS ON				← PICKUP IS OFF

