

JEFF BECK STRATOCASTER 0109600

SWITCH & CONTROL FUNCTION

5 POSITION SWITCH FUNCTION DIAGRAM							
							← INDICATES POSITION OF 5 WAY SWITCH (S2)
			S1 SWITCH IS DOWN	S1 SWITCH IS UP	S1 SWITCH IS DOWN	S1 SWITCH IS UP	← SWITCH (S1)
T1	T1 & T2	T2	T2	T2	T2	T2	← TONE CONTROL (T1,T2)
							← NECK PICKUP (A)
							← MIDDLE PICKUP (B)
							← BRIDGE PICKUP (C)
							← BRIDGE PICKUP (D)

	PICKUP IS ON
	PICKUP IS OFF

