












AMERICAN TELECASTER 0118400/8402

SWITCH & CONTROL FUNCTION

3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		PICKUP IS OFF

