

STANDARD STRATOCASTER LEFT HAND 0134620/4622

SWITCH & CONTROL FUNCTION

| 5 WAY SWITCH POSITION | | | | | |
|-----------------------|--------------|----|----|---|-------------------------|
| | | | | | ← 5 WAY SWITCH POSITION |
| T1 | T1&T2 | T2 | T2 | — | ← TONE CONTROL |
| | | | | | ← NECK PICKUP |
| | | | | | ← MIDDLE PICKUP |
| | | | | | ← BRIDGE PICKUP |
| | PICKUP IS ON | | | | PICKUP IS OFF |

