

STANDARD TELECASTER 0135102

REF.#	P/N	DESCRIPTION
1	0037431000	Neck, Tele., Mex M/N
2	0037429000	Tuning Key, (1) Set
	0053106000	Washer Key Ping
	0053107000	Bushing
3	0083675000	Bone Nut
4	0010389000	String Retainer
	0011357000	Mounting Screw
5	0038454000	Truss Rod Adjustment Nut
	0038467000	Truss Rod Adjusting Wrench
6	0053153xxx	Body, Std. Tele, Mex, Paint
	0053154xxx	Body, Std. Tele, Mex, Sunburst
7	0033024000	Neck Mounting Plate
	0015636000	Mounting Screw
8	0012344000	Strap Button
	0020491000	Felt Washer, White
	0015610000	Mounting Screw
9	0028178002	Pickguard, Std. Tele, White/Black/White
	0015578000	Mounting Screw
10	0041620000	Pickup, Neck
	0021409000	Mounting Screw
	0036878000	Tubing, Latex Cut
11	0029044000	Pickup, Bridge
	0048631000	Mounting Screw
	0036878000	Tubing, Latex Cut
12	0019064000	Control, 250k (2)
	0016352000	Mounting Hex Nut
	0016436000	Washer, Lock Intl.
13	0013359000	Knob, Knurled Chrome (2)
	0028897001	Screw Set (2)
14	0040778000	Plate, Control
	0015578000	Mounting Screw
15	0053290000	Switch, Lever 3-Position
	0018359000	Knob, Black
	0021413000	Mounting Screw
16	0015552000	Capacitor, .05uF
17	0047329000	Output Jack
18	0021452000	Ferrule, Jack
	0010355060	Retainer Jack, Ferrule
19	0021429000	String Retainer, Ferrule
20	0053356000	Bridge Assy, Std. Tele.
	0016188000	Mounting Screw
21	0053354000	Bridge Plate, Std. Tele.
	0016188000	Mounting Screw

Body Part Number	
0053154532	BrownSunburst
0053153506	Black
0053153573	Midnight Blue
0053153575	Midnight Wine
0053153580	Artic White