


STANDARD TELECASTER 0135102

CONTROL & SWITCH FUNCTION



3 WAY SWITCH POSITION				
			← 3 WAY SWITCH POSITION	
			← NECK PICKUP	
			← BRIDGE PICKUP	
	PICKUP IS ON			PICKUP IS OFF

