


'72 TELECASTER THINLINE 0137402

SWITCH & FUNCTION CONTROL



DETAIL 3 WAY SWITCH DIAGRAM

3 WAY SWITCH POSITION			
● 3 ○ ○	○ 2 ● ○	○ ○ 1 ●	← 3 WAY SWITCH POSITION
■	■	□	← NECK PICKUP
□	■	■	← BRIDGE PICKUP
□	PICKUP IS OFF	■	PICKUP IS ON

NECK PICKUP
HUMBUCKER

BRIDGE PICKUP
HUMBUCKER

SEE 3 WAY SWITCH
& DETAIL DIAGRAM ○ 3
○ 2
○ 1

MASTER VOLUME

MASTER TONE