


'MUDDY WATERS TELECASTER 0138500

SWITCH & CONTROL FUNCTION



3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
MT	MT	MT	← TONE CONTROL
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		PICKUP IS OFF

