



# JAMES BURTON STANDARD TELECASTER 0138602

## SWITCH & CONTROL FUNCTION



DETAIL  
3 WAY SWITCH

3 WAY SWITCH POSITION				
			← 3 WAY SWITCH POSITION	
			← NECK PICKUP	
			← BRIDGE PICKUP	
	PICKUP IS ON			PICKUP IS OFF



○ 3  
○ 2  
○ 1