STU HAMM "URGE" BASS II 0191500

SWITCH & CONTROL FUNCTION

ACTIVE DYNAMIC CONTROL POSITION	3 WAY SWITCH POSITION		
	1	2	INACTIVE DYNAMIC CONTROL IN NO. 3 POSISTION 3
A			
A & C			
C			

▬	PICKUP IS ON
▭	PICKUP IS OFF
A	J - B PICKUP (NECK)
B	P - B PICKUP (MIDDLE)
C	J - B PICKUP (BRIDGE)

INDICATES POSITION OF 3 WAY SWITCH

1 2 2



MASTER VOLUME CONTROL

DYNAMIC CONTROL

BASS & TREBLE CONTROL

MIDDLE CONTROL

CW - BOOST
CCW - CUT

SEE SWITCH DIAGRAM
POSITION 1 - 2 & 3